


B/W Scan to Computer (Konica Minolta 751 Photocopier)

Operation Instruction

(i) Insert Octopus card to card reader

(ii) Load the original





(iii) Press [Fax / Scan] button



(iv) Specify the destination computer

(v) Configure Scan option settings as necessary



(vi) Press the **Start** key to scan

(vii) After all originals are scanned, tap **[Finish]** and press the **Start** key

