


Wi-Fi Scanning

For IOS (9.0 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation


1. Connect Mobile to Wi-Fi



2. Installation



3. Add Printer and Print Setting




I. Tap [Scan] in the Main Menu

Wi-Fi Scanning

For IOS (9.0 or above)


富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

II. Please refer to the table below for all the IP addresses:




Machine No.	Floor	IP Address
A5	G/F	192.168.223.32
B4	1/F	192.168.223.33
C3	2/F	192.168.223.34
D3	3/F	192.168.223.51
D5	4/F	192.168.223.52


4. On Printer



I. Tap [Store to WSD] in the Main Menu



II. Tap [Operate From Computer]




III. Ready for Scanning

Wi-Fi Scanning

For IOS (9.0 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

5. Start Scanning



Scan Setting

- I. Select Paper Source
** Flatbed only for single original, select Feeder for multiple original.*
- II. Select Scan Color
- III. Select the Scan File Format

Tap [Scan] to start scanning

6. Finished Scanning

Select suitable action after scanned

