


Wi-Fi Printing

For IOS (9.0 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

1. Connect Mobile to Wi-Fi






Must select [EdUHK/EdUHK5G]

2. Installation



Install [Fuji Xerox Print Utility] from App Store

3. Add Printer



Please refer to the table below for all the IP addresses:




Machine No.	IP Address
F1	192.168.225.34

Wi-Fi Printing

For IOS (9.0 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation


4. Print Setting




I. Tap [Print] in the Main Menu

II. Tap desired file to print

III. Tap [Settings] at the top menu



IV. Tap [Accounting]




V. Set the Billing ID and Passcode (Self-Assigned)

Wi-Fi Printing


For IOS (9.0 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation


4. Insert Octopus Card



I. Select [Use Octopus] on Octopus Processor




II. Insert Octopus card and click [Confirm] on Octopus Processor




III. Octopus Processor will show the usable value


5. On Printer




I. Tap [Charge Print] on the Menu of the Printer



II. Select the Billing ID entered before




III. Input [Passcode]



IV. Select your print job and tap [Preview]




V. Or Tap [Print] to start printing




VI. Tap [Print] to start printing

6. Remove Octopus card



I. Select [Finish Copying] on Octopus Processor



II. Select [Confirm] on Octopus Processor



III. Remove Octopus card