


Wi-Fi Printing

For Android (4.4 or above)



富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

1. Connect Mobile to Wi-Fi






Must select [EdUHK/EdUHK5G]

2. Installation



Install [Fuji Xerox Print Utility] from Play Store

3. Add Printer



Please refer to the table below for all the IP addresses:


Machine No.	IP Address
F1	192.168.225.34

Wi-Fi Printing


For Android (4.4 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation


4. Printing



a. Tap [Print] in FUJI XEROX application




b. Tap desired file to print




c. Change desired [Settings]


Other than using FUJI XEROX application, you can “Share” with FUJI XEROX for printing



d. Tap [Advanced]



e. Tap [Accounting]




f. Set the Billing ID and Passcode (Self-Assigned) and Tap [Print] to start the print

Wi-Fi Printing


For Android (4.4 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

5. Insert Octopus Card



I. Select [Use Octopus] on Octopus Processor




II. Insert Octopus card and click [Confirm] on Octopus Processor




III. Octopus Processor will show the usable value

6. On Printer




I. Tap [Charge Print] on the Menu of the Printer



II. Select the Billing ID entered before




III. Input [Passcode]



IV. Select your print job and tap [Preview]




V. Or Tap [Print] to start printing




VI. Tap [Print] to start printing

7. Remove Octopus card



I. Select [Finish Copying] on Octopus Processor



II. Select [Confirm] on Octopus Processor



III. Remove Octopus card