


Wi-Fi Scanning

For Android (4.4 or above)



富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

1. Connect Mobile to Wi-Fi





Must select [EdUHK]

2. Installation



Install [Fuji Xerox Print Utility] from Play Store

3. Add Printer



Please refer to the table below for all the IP addresses:



Machine No.	Floor	IP Address
	G/F	192.168.223.36
	1/F	192.168.223.53

Wi-Fi Scanning

For Android (4.4 or above)

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

4. Start Scanning



Scan Setting

- I. Select Scan Method
- II. Select Image Type
- III. Select the Scan File Format

Tap [Scan] to start scanning

6. Finished Scanning

Select suitable action after scanned

