Wi-Fi Scanning

FUJI XEROX

*For Android (4.4 or above)*

富士施樂『八達通』自助影印服務使用指示
FUJI XEROX Octopus Self Copy Service Operation

1. Connect Mobile to Wi-Fi

Must select [EdUHK]

2. Installation

Install [Fuji Xerox Print Utility] from Play Store

3. Add Printer

Please refer to the table below for all the IP addresses:

| Machine No.	Floor	IP Address
A5	G/F	192.168.223.32
B4	1/F	192.168.223.33
C3	2/F	192.168.223.34
D3	3/F	192.168.223.51
D5	4/F	192.168.223.52

4. On Printer

I. Tap [Store to WSD] in the Main Menu

II. Tap [Operate From Computer]

III. Ready for Scanning

5. Start Scanning

Scan Setting

I. Select Paper Source
* Flatbed only for single original, select Feeder for multiple original.

II. Select Scan Color

III. Select the Scan Fie Format

Tap [Scan] to start scanning

6. Finished Scanning

Select suitable action after scanned